

Nitrate Sensor



Aqua TROLL 500/600/700/800 Nitrate Sensor

The In-Situ nitrate sensor measures nitrate levels in natural water, surface water, groundwater, produced water and aquaculture applications.



You must have a **Temperature** or **Conductivity/Temperature** sensor installed to use the Nitrate sensor.

Getting Started (4 steps)

Replace the reference filling solution.



Before calibration and deployment, condition the nitrate sensor and replace the filling solution according to the instructions below. Repeat conditioning procedure between deployments.



Unscrew reference junction.



Don't pour solution down the drain. Pour it onto a paper towel and discard.



Lightly shake the bottle of reference filling solution to mix.



Insert the fill tube into the bottom of reservoir.



Squeeze a steady stream of solution into the reservoir while slowly pulling out the tube.



Overfill slightly. Reinstall reference juntion cap and tighten until it touches sensor body.



Turn the cap 90° more (one quarter of a turn) to secure.

Page 1 970-498-1500 www.in-situ.com 2024-02-22 | 0033712

Condition the sensor.



Soak sensor for a minimum of two hours in 140 mg/L nitrate as N standard or the highest standard you plan to use during calibration.



Soak overnight for the best long-tem results. Rinse thoroughly with deionized water prior to calibration.

3

Install sensor.



Remove restrictor from the instrument.



Remove sensor port plug if installed. Do not twist.



Lubricate o-ring at bottom of sensor.



Install sensor. Do not twist.




Place instrument in calibration mode.



Calibrate and deploy.



Connect to the instrument with VuSitu.



Select Calibrations from the menu.



Choose the Nitrate option and follow the instructions.



Flip the restrictor into deployment mode after calibration

Page 2 970-498-1500 www.in-situ.com 2024-02-22 | 0033712



For detailed calibration instructions, see the instruction manual or quick start guide for your In-Situ instrument.

Cleaning and Storing the Sensor



Do not store the Nitrate sensor in DI water. It will deplete the reference solution and drastically reduce the life of the sensor.

Storage



Dampen the sponge inside the sensor storage cap with Storage Solution or pH 4 calibration standard.



Replace the caps at both ends of the sensor. Use electrical tape to seal the storage cap.



Salt crystals may form on the sensor during storage. These are normal and will not interfere with sensor performance.

Page 3 970-498-1500 www.in-situ.com 2024-02-22 | 0033712